

REQUIRED PRODUCTS:

- [Fresco paintbrush](#)
- [Wallprim primer*](#)
- [Fresco lime paint](#)
- [Dead Flat Sealer*](#)

Calculators:

[Wallprim Paint](#)

[Fresco Paint](#)

[Dead Flat Sealer Paint](#)

Wallprim: Fresco will not properly adhere to synthetic or sealed surfaces, including drywall, sheetrock, previously painted walls, standard primers, and other non-mineral substrates. Applying Fresco without Wallprim (or Omniprim) may result in poor adhesion, uneven absorption, or premature failure of the finish.

Dead Flat Sealer: For high-traffic areas or high-humidity areas, extra protection is required. You can use our Dead Flat Eco sealer for that purpose, a matte, transparent, non-yellowing sealer.

After 7 days (let the lime fully cure), apply 1-3 thin layers of Dead Flat Eco Sealer with a brush (a Fresco brush works best) in the same direction as the Fresco strokes.

We recommend diluting the Dead Flat with 5-10% water and applying ultra-thin coats with a brush for the best results and optimal adhesion.

!! Don't forget to read the [step-by-step instructions](#) and pro tips on [the Fresco page](#) and [Dead Flat Sealer page](#) carefully!