

## PURE & ORIGINAL - MASSIF - WALL PREPARATION FOR SHOWERS

Here are the details to follow for an optimal installation.

Pure & Original products to order:

- Omniprim primer
- Massif - micro-stone
- 2K Varnish
- Specialized painting tools

Mapei waterproofing products to order:

- Mapei Mapelastic 315 - *or a similar product* -
- Mapei Fibre Glass Mesh (for joints) - *or a similar product* -

Waterproofing steps

1. Seal the walls of the shower with Mapei Mapelastic 315, following the guidelines of Mapei.
2. Integrate the Mapei Fibre Glass Mesh into the layer of Mapelastic 315 to ensure optimal waterproofing and stability.
3. Ensure that the surface is flat and level at the time of application. If necessary, level slightly using the Mapelastic 315 (the fibre texture should not be visible!).
4. Let the membrane completely harden, then perform a waterproofing test before proceeding with the work. The substrate has to be smooth and waterproof.

Application of the Pure & Original Massif finish

1. Read the attached [technical documents](#) carefully before the application.
2. Undercoat: Apply a decent layer of Omniprim on the Mapelastic membrane, in accordance with the recommendations of Pure & Original.
3. Finish: Apply the Massif finish, according to [the instructions](#) of Pure & Original.
4. Final protection: Wait 7 days after applying the Massif before applying two coats of 2K Varnish Ultra Mat sealant for optimal cleanability and stain resistance.

It is important to do a test before starting the project.

This test will allow you to familiarize yourself with the products and to have an overview of the final results.