

## MASSIF | APPLICATION INFORMATION

### TOOLS:

A roller, a brush, a special roller for micro stone or block brush, the Massif flexible spreader, hand sanding machine, 120-grit sanding paper and a trowel with rounded edges like the Marrakech trowel.

Ensure that the substrate is appropriately prepared based on the type of underground and the project's purpose. The substrate must be completely smooth, and any seams must be addressed before applying Massif; connecting panels require at least a level 4 finish (taped). Consult the Technical Sheet for more detailed information.

### HOW TO APPLY:

**1 A** Tape the edges, protect the floor, remove dust and clean the wall if needed.

**1 B** Spot-prime repair spots and plaster seams with Pure & Original Wallprim or Omniprim.

**1 C** With a roller, apply one layer of Pure & Original Wallprim or Omniprim (in same color as Massif). Dilute the primer with max 10% water. Let it dry for 4 hours

**2** Stir the Massif well, do not dilute. For bigger projects, mix and match the different cans.

**3** Apply a thin coat of Massif with the special roller or block brush and spread it out with the Marrakech trowel in different directions. Let it dry for 48 hours; **do not cover the paint during drying.**

**4** Sand the surface lightly with 120-grit sanding paper; a hand machine works best. Remove dust with a lint-free, damp cloth.

**5** Apply the second thin scrape coat (skim coat) and spread it with the Massif flexible spreader in different directions until a smooth finish. Accept that there will be some trowel lines.

**6** Leave the finish as it is (coarse) or sand it again after one or two days. Sanding will provide more nuance, and a smoother surface is easier to clean.

### OPTIONAL:

**Protective finish:** Massif is naturally water repellant, yet we recommend protections with Varnish Ultra Matte 1K or 2K (check technical sheet for detailed advice) for areas exposed to significant amounts of water. You must allow a drying time of 7 days before applying the Varnish. **Do not cover the paint during drying.**

**Application of Varnish:** Stir well and apply two thin (or three) coats with a flat, stiff-bristle brush like our Spalter brush.

Pure & Original and Pure & Original USA-Canada cannot be held responsible for the execution of preparation, application and further processing of the products, since it is beyond our control how products are applied, what the condition of surfaces and environments are and decisions made regarding products or colors

Note: this is a general application instruction and does not replace the technical datasheet. Technical datasheet is available at [www.pure-original.com](http://www.pure-original.com).