

Licetto paint | APPLICATION INFORMATION

Tools: Brush, roller (5-6 mm roller for smooth surfaces, lint free) and tape.

HOW TO APPLY:

Dilute Licetto with water, max 10%. Apply as any other wall paint with a brush, a smooth roller or by spraying.

Make sure the substrate is free of fat, dust and loose parts.

It's recommended to roughen glossy paint finishes slightly with sanding paper for maximum adhesion.

For substrates with high absorption, the recommendation is priming the surface with Wallprim. Spot-prime repair spots first, to prevent differences in absorption.

SPRAY:

Pressure Airless; min. 150 bar

Tip; 0,018" - 0,021"

Angle; 40° - 50°

Dilution; 0 - 10%

Spray pressure; 16,5 MPa (165 atm)

Nozzle; ca. 0,46 - 0,53 mm / 0,018 - 0,021 inch

Waiting time: about 4 hours before applying the second coat.

Furniture/Cabinets: Some of those surfaces might need extra attention. Old finishes may contain wax, grease/oil or silicone. If that's the case (or if you're not sure) we recommend cleaning the surface with Pure & Original Super Cleaner. Silicons need to be sanded down.

Protect bleeding types of wood with Omniprim or a shellac.

Pure & Original and Pure & Original USA-Canada cannot be held responsible for the execution of preparation, application and further processing of the products, since it is beyond our control how products are applied, what the condition of surfaces and environments are and decisions made regarding products or colors

Note: this is a general application instruction and does not replace the technical datasheet. Technical datasheet is available at www.pure-original.com